



微耕机机组零部件图册

PARTS CATALOGUE



1WG5.2-120FQ-ZA

Version number: LC/LT-2016-A

隆鑫通用动力股份有限公司

LONCIN MOTOR CO.,LTD.

本零件目录是 据2016年01月所能得到的最新资料编制而成的。

This parts catalogue was prepared based on the latest information available as of January 2016.

请注意2016年01月以后本零部件目录的修订通知。

See the parts catalogue news for any revision that is made after January 2016.

当订购零件时，一定要明确指出其零件编号。

Always specify the part number when ordering a part.

注意本零件目录所给出的图形可能与实际零件外形有所不同。

Note that the illustrations can differ from the actual parts in shape.


当需要对零部件目录的内容进行更 或增加时，本公司将在适当的时间出版修订版，为保证在任何时候都可以使用到最新版本的零部件目录, 建议拥有最新的修订版本。如果要检查修订版本是否已经发行，请直接与LONCIN联系。

When modifications or additions to this parts catalogue are made , a revised edition will be issued at an appropriate time, We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a part scatalogue revision has been issued, please contact your LONCIN distributor.


示例 (Example)

序号 No.	零部件件号 Part No.	零部件名称	Description	数量 (Reqd. QTY.)
1	191910005-0001	减速箱体	Gear Box	1


序号 NO.	零部件件号	零部件名称	Description	数量 (Reqd. QTY)
1	341920039-0001	发动机护罩	Engine Protect Cover	1
2	283920004-0001	照明灯	Lamp LED	1
3	380310015-0005	十字槽盘头自攻螺钉	Bolt ST3.5X12	3
4	344010012-0001	发动机护罩支架_后	Protect Cover Stents	1
5	110690053-0001	机油尺组合	Dipstick	1
6	175F-2	发动机	Engine	1
7	111360001-0001	传动箱法兰盘密封垫	Flange Cushion	1
8	192050078-0001	变速机构组件	Variable Speed Instutions	1
9	110200017-0001	传动箱密封垫	Gear Box Cushion	1
10	380460002-0006	弹性垫圈10 GB/T93	Elasticity Cushion	6
11	380070100-0004	六角头螺栓M10X40	Bolt M10X40	2
12	380070103-0004	六角头螺栓M10X35	Bolt M10X35	3
13	380070170-0001	六角头螺栓M10X30	Bolt M10X30	1
14	380310137-0001	十字槽盘头自攻螺钉	Bolt ST5X13	2
15	344010009-0001	发动机护罩支架_上	Protect Cover Stents	1
16	380350003-0002	非金属嵌件锁紧螺母	Nut M6	1
17	380140538-0001	六角头法兰面螺栓	Bolt M6X90	1
18	344010010-0001	发动机护罩支架_下	Protect Cover Stents	1
19	380350006-0001	非金属嵌件六角锁紧螺母	Nut M8	4
20	380460001-0006	平垫圈 8	Washer 8	4
21	300110142-0001	发动机托架	Bracket	1
22	380350009-0001	非金属嵌件六角锁紧螺母M10	Nut M10	3
23	380450006-0005	平垫圈	Washer 10	6
24	380070100-0004	六角头螺栓M10X40	Bolt M10X40	3
25	380140051-0005	六角头法兰面螺栓	Bolt M8X35	4
26	380020133-0001	六角头轴肩螺栓	Bolt ø8X38	1
27	380610157-0001	销轴	Pin Shaft ø8	1
28	381350011-0001	销夹 ø2.5Xø9X46	Pin Nip	1
29	380350003-0002	非金属嵌件六角锁紧螺母	Nut M6	1
30	380450729-0001	平垫圈	Washerø6X16X1.5	1



序号 NO.	零部件件号	零部件名称	Description	数量 (Reqd. QTY)
1	661500015-0001	右耕刀部件	Blade Assembly,RH STD	1
2	381350011-0001	销夹 $\varnothing 2.5 \times \varnothing 9 \times 46$	Pin Nip	3
3	380610047-0001	销轴 B8X50	Pin Shaft B8X50	2
4	195150002-0001	前驱输出轴套	Precuirsor Output Collar	2
5	195640007-0001	输出轴防尘盖	Dustproof Cover	2
6	193050025-0001	输出轴	Output Shaft	1
7	661490018-0001	左耕刀部件	Blade Assembly,LH STD	1
8	380350009-0001	非金属嵌件六角锁紧螺母	Nut M10	5
9	380450006-0005	平垫圈10 GB/T97.1	Washer 10	7
10	380070326-0001	六角头螺栓M10X50	Bolt M10X50	3
11	661380004-0001	阻尼安装座	Damping Seat	1
12	380070018-0004	六角头螺栓 M8X20	Bolt M8X20	4
13	380450524-0001	平垫圈 $\varnothing 8.5 \times \varnothing 23 \times 3$	Washer 8	4
14	380350003-0002	非金属嵌件六角锁紧螺母	Nut M6	8
15	380450004-0003	平垫圈6 GB/T97.1	Washer 6	8
16	661530044-0001	挡泥板支架_右	Fender Bracket	1
17	661530043-0001	挡泥板支架_左	Fender Bracket	1
18	661530045-0001	挡泥板支架_后	Fender Bracket	1
19	380070170-0001	六角螺栓M10X30	Bolt M10X30	2
20	661390006-0001	阻尼臂固定座	Damping Arm Seat	1
21	381350012-0001	销夹 $\varnothing 3.5 \times \varnothing 13 \times 81$	Pin Nip	1
22	661550004-0001	阻尼臂吊销	Pin	1
23	380140013-0005	六角兰面螺栓 M6X16	Bolt M6X16	8
24	661420024-0001	左挡泥板	Left Fender	1
25	661430023-0001	右挡泥板	Right Fender	1
26	380610184-0001	销轴 $\varnothing 12 \times 40$	Pin Shaft	1
27	661400002-0002	阻尼臂	Damping Arm	1
28	380340012-0005	六角螺母 M12	Nut M12	2
29	380070228-0002	六角螺栓M12X40	Bolt M12X40	2



序号 NO.	零部件件号	零部件名称	Description	数量 (Reqd. QTY)
1	196280004-0001	换挡手柄	Shift Handle	1
2	171210422-0001	油门拉索	Rope	1
3	196780019-0001	倒档拉索	Rope	1
4	320180196-0001	手把胶	Armrest Rubber Handle	2
5	271510151-0001	左手柄部件	Left Handle Parts	1
6	271660086-0001	熄火开关	Switch	1
7	271510177-0001	左手柄部件	Left Handle Parts	1
8	320240474-0001	离合拉索	Rope	1
9	662680001-0001	旋转拉索	Rope	1
10	320010245-0001	手把管组合	Mulriple Armrest	1
11	331510094-0001	U形抱箍	U Hold Hoop	2
12	380140071-0002	六角头法兰面螺栓M8X40	Bolt M8X40	1
13	381160237-0001	扭簧	Spring	1
14	380350003-0002	非金属嵌件六角锁紧螺母M6	Nut M6	2
15	661750005-0001	升降手柄	Hand Shank	1
16	380450003-0006	平垫圈GB/T97.1	Washer 8	4
17	380350006-0001	非金属嵌件六角锁紧螺母	Nut M8	4
18	380450004-0003	平垫圈GB/T97.1 6	Washer 6	1
19	341620018-0001	手把管护罩	Handgrip Cover	1
20	320050099-0001	手把管连接座	Join Seat, Armrest	1
21	192780063-0001	换挡拉索	cord	2
22	380070050-0002	六角头螺栓M8X16	Bolt M8X16	2
23	380460001-0006	弹性垫圈GB/T93 8	Elasticity Cushion	2
24	660190088-0001	支座	Seat	1
25	284920002-0001	照明灯开关	Lighting switch	1
26	380350009-0001	非金属嵌件六角锁紧螺母M10	Nut M10	4
27	191800017-0001	支撑座	Supporting Seat	1
28	380070100-0004	六角头螺栓M10X40	Bolt M10X40	4
29	296270003-0001	定位螺钉	Bolt	1
30	381150629-0001	压簧	Spring	1





隆鑫通用动力股份有限公司

Loncin motor co., Ltd.

详细地址：重庆市九龙坡区九龙工业园区华龙大道99号

Add: No. 99 Hualong Road, Jiulongpo District, Chongqing, China

Tel: 86 23 8980 5678 / 86 23 8980 8505

Fax: 86 23 8906 7566

Email: service@loncinengine.com

Website: www.loncinengine.com

PRINTED IN CHINA